

User Guide for Laptop Battery

Guidelines

Setup

- On first use, discharge battery to 3%, then fully charge to 100%.
- Recharge battery immediately when it reaches 3%.

Keeping the Battery Healthy

- After the battery is discharged, recharge it within 2 days.
- If the battery hasn't been used for 3 months or more, the battery should be charged to a minimum of 50%.
- The battery should be constantly charged and discharged in daily use.
- If the battery is not used daily, discharge and recharge to 100% **every two months**.
- The battery life lasts safely for two years. We recommend taking the battery out of the laptop and stop using it after 2 years, **or else you risk a fire or an explosion**.

Never take out the battery from the laptop when it is in use.

Never discharge the battery below 3%.

If battery fails to charge:

Switch off your laptop and try charging again. If it still fails, it could be one of the following problems.

- **Your adapter is not compatible with the laptop.** If so, try and find a compatible adapter.
- **The adapter is damaged.**